

INOGENI SHARE2U

Firmware upgrade procedure from v1.x to v2.x

PREREQUISITES PRIOR TO THE UPGRADE

Here are the prerequisites to successfully upgrade your unit from v1.x to v2.x firmware.

- You must have a FAT32 formatted USB drive with at least 1GB of free space.
- Here is the formatting of the device serial number:
 - SHARE2U: SU[A][BBB][CCCC]
 - ⇒ [BBB] must be equal or greater than 111.
- Your unit must run **application version greater or equal to 1.12.20** to support this upgrade process.
- You must have the "inogeniupdate_V2_X_Y.zip" package that you can get from our support team. Contact support@inogeni.com to get this package.



Device configuration will be lost after the upgrade.

Please backup important information like network configuration and user settings. You cannot revert to the original firmware after this operation.

UPGRADE PROCEDURE


Here is the procedure for upgrading your unit.

1. Get CPU Firmware Package:


- Obtain the firmware package (inogeniupdate_V2_X_Y.zip compressed file) from our support team.
- If you need help, please contact support at <u>support@inogeni.com</u>.

2. Prepare USB Drive:

- Extract the firmware package (inogeniupdate_V2_X_Y.zip compressed file) on your computer.
- o Browse to the extracted archive.
- o Copy the "inogeniupdate" folder to the root of your FAT32 formatted USB drive.



Eject safely the USB drive from your computer and disconnect it.



3. Power Down Device:

Unplug the power and the cameras connected to your SHARE2U unit.

4. Connect USB Drive:

o Plug the USB drive into the USB camera port of your device.



5. Power Up Device:

- Connect power to your SHARE2U unit.
- After a few seconds, all front LEDs will light up, indicating the upgrade process has started.



Do not disconnect power during this process to avoid bricking your unit.



6. Wait for Completion:


- The upgrade process can take up to 5 minutes.
- Wait until the front LEDs are flashing continuously.

7. Finalize CPU Update:

- o When the LEDs are flashing continuously, disconnect the USB drive.
- o Power cycle your unit.

8. USB controller / Video processor Update:

- Kindly connect your device to your computer using a USB-B to USB-A cable. Please use the <u>INOGENI</u>
 <u>Maestro v2.2.0</u> software to update both the USB Controller and Video Processor firmwares with the official firmware package (ZIP file) available on the product webpage.
- o Navigate to SYSTEM tab >> UPDATE section and browse for the firmware ZIP file
- Click on UPDATE button.



Let the update finish until the software says it is completed.



Your device is now updated to the latest firmware! You can now use the INOGENI Maestro v2.2.0 to monitor and configure your unit.